

CORIOLISS

MANUAL DE LIMPIEZA - MISTRAL

- **1º PASO: Apaga el secador** antes de comenzar cualquier tarea de limpieza.


- **2º PASO: Retira el filtro, la rejilla metálica y la esponja protectora** para garantizar una limpieza más eficaz. (Foto 1)



- **3º PASO: Con el secador apagado y las piezas retiradas, presiona el botón central y, a continuación, el botón de encendido** para activar el sistema de limpieza. (Foto 2)



- **4º PASO: Limpia la rejilla metálica con alcohol y la esponja protectora con agua y jabón** eliminando correctamente los restos de resinas y suciedad acumulada. (Foto 3)



- **RECOMENDACIONES:**

Uso profesional: Limpieza diaria.

Uso particular: Limpieza 1 vez a la semana

CORIOLISS

CLEANING MANUAL - MISTRAL

- **1st STEP:** Turn off the hair dryer before starting any cleaning process.


- **2nd STEP:** Remove the filter, the metal grille and the protective sponge to ensure a more effective cleaning. (Photo 1)



- **3rd STEP:** With the hair dryer turned off and the parts removed, **press the central button and then the power button** to activate the cleaning system. (Photo 2)



- **4th STEP:** Clean the metal grille with alcohol and the protective sponge with soap and water effectively removing resin and accumulated residue. (Photo 3)



- **RECOMMENDATIONS:**
Professional use: Daily cleaning.
Personal use: Clean once a week.