



CORIOLISS

MANUAL DE LIMPIEZA WHISPER

- **1º PASO:** Se debe realizar una limpieza manual del filtro interior con la ayuda del cepillo pequeño. para ello, hay que extraer la tapa, la rejilla trasera y el cazo interior, como en la imagen (1), y limpiar el cazo interior.
- **2º PASO:** Para activar la función de **auto-limpieza**, desenchufa el aparato y quita los accesorios (boquilla y difusor). Retira el filtro de admisión de aire girándolo en sentido contrario de las agujas del reloj (1). Ajusta la posición del botón a Standby, como en la imagen (2). Enchufa el aparato y mantén apretados los botones del ventilador y de la temperatura a la vez durante 5 segundos como en la imagen (3). La función de auto-limpieza terminará después de 10 segundos y el motor se desconectará automáticamente.
- **RECAMBIOS Y ACCESORIOS INCLUIDOS:** Incluye **2 filtros de esponja**, **1 filtro metálico** y un **cepillo para limpiarlo** (4).
- **RECOMENDACIONES:**
Limpiar la esponja que protege el filtro con agua tibia y el filtro metálico con alcohol para eliminar resina y suciedad acumulada.
 - **Uso profesional:** Limpieza diaria.
 - **Uso particular:** Limpieza cada 10 días.



CORIOLISS

CLEANING MANUAL - WHISPER

- **STEP 1:** The internal filter must be manually cleaned using the small brush. To do this, remove the lid, the rear grille, and the inner bowl, as shown in image (1), and clean the inner bowl.
- **2nd STEP:** To activate the self-cleaning function, unplug the appliance and remove the accessories (nozzle and diffuser). Remove the air intake filter by turning it counterclockwise (1). Set the button to Standby, as shown in the image (2). Plug in the appliance and press and hold the fan and temperature buttons simultaneously for 5 seconds, as shown in the image (3). The self-cleaning function will finish after 10 seconds, and the motor will automatically switch off.
- **REPLACEMENT PARTS AND ACCESSORIES INCLUDED:** Includes **2 sponge filters, 1 metal filter and a cleaning brush** (4).
- **RECOMMENDATIONS:**
Clean the sponge protecting the filter with warm water and the metal filter with alcohol to remove resins and accumulated dirt.
 - **Professional use:** Daily cleaning.
 - **Personal use:** Cleaning every 10 days.

